## **ALPHA RANGE**

## **INSTRUCTION OF USE**

To adjust back height hold back INDOOR USE ONLY with two hands while seated and raise to desired height To lower the back height raise back all the way to the top **OPTIONAL** and release slowly **ADJUSTABLE ARMS** RIGHT BACK LEVER To adjust back angle RIGHT FRONT LEVER **LEFT LEVER** To adjust seat height To adjust seat anale **600MM BLACK NYLON 5 STAR BASE** WITH CASTORS Use soft tyred castors for tiles Use hard tyred castors for carpet **X** Do not use as a step ladder

## **DIMENSIONS: (mm)**

LOW BACK	LOW BACK TO FLOOR	HIGH BACK	HIGH BACK TO FLOOR	SEAT	SEAT TO FLOOR	ARM TO FLOOR
W: 440	Lowest: 935	W: 450	Lowest: 1020	W: 500	Lowest: 485	Lowest: 630
H: 460	Highest: 1120	H: 560	Highest: 1240	D: 460	Highest: 625	Highest: 840



## Features:

Adjustable seat height Adjustable back height (ratchet) Adjustable seat angle (with 3 lever mechanism only) Adjustable back angle Optional 2 or 3 lever mechanism Moulded seat and back foam Java seat









600mm black nylon 5 star base Available in local fabrics AFRDI tested to level 6 Suitable for indoor use only