

# SAFARI RANGE

## INSTRUCTION OF USE

To adjust back height hold back with two hands while seated and raise to desired height

To lower the back height raise back all the way to the top and release slowly

### **RIGHT BACK LEVER**


To adjust back angle

### **RIGHT FRONT LEVER**

To adjust seat height

### **700MM BLACK NYLON 6 STAR BASE WITH CASTORS**

Use soft tyred castors for tiles  
Use hard tyred castors for carpet



**INDOOR USE ONLY**

**OPTIONAL  
ADJUSTABLE ARMS**

**LEFT LEVER**

To adjust seat angle

**X** Do not use as a step ladder

## DIMENSIONS: (mm)

### **LOW BACK    LOW BACK TO FLOOR**

W: 440    Lowest: 930  
H: 400    Highest: 1140

### **HIGH BACK    HIGH BACK TO FLOOR**

W: 450    Lowest: 990  
H: 510    Highest: 1185

### **SEAT**

W: 530  
D: 480

### **SEAT TO FLOOR**

Lowest: 530  
Highest: 670

### **ARM TO FLOOR**

Lowest: 670  
Highest: 880

Fabric: Chelsea bark



SA350H



SA350



SA200

Optional:



Drafting kit



Adjustable arm

## Features:

Adjustable seat height  
Adjustable back height (ratchet)  
Adjustable seat angle  
(with 3 lever mechanism only)

Adjustable back angle  
Optional 2 or 3 lever mechanism  
Moulded seat and back foam  
Firm kidney and lumbar support

Big boy seat  
700mm black nylon 6 star base  
Available in local fabrics  
Suitable for indoor use only

