


# BRAGG RANGE

## INSTRUCTION OF USE

**INDOOR USE ONLY**



**OPTIONAL  
ADJUSTABLE  
HEADREST**

**ADJUSTABLE ARMS**

**INNER LEFT LEVER**  
To adjust seat depth  
(seat slider)

**RIGHT LEVER**  
To adjust seat height

**LEFT LEVER**  
To adjust seat  
and back angle

**640MM BLACK HIGH ARCH 5 STAR  
BASE WITH CASTORS**

Use soft tyred castors for tiles  
Use hard tyred castors for carpet

**X Do not use as a step ladder**

## DIMENSIONS: (mm)

**BACK**    **BACK TO FLOOR**  
W: 470    Lowest: 1075  
H: 650    Highest: 1150

**HEADREST**    **HEADREST TO FLOOR**  
W: 320    Lowest: 1210  
H: 190    Highest: 1370

**SEAT**    **SEAT TO FLOOR**  
W: 510    Lowest: 495  
D: 510    Highest: 570

**ARM TO FLOOR**  
Lowest: 660  
Highest: 810

\* Please note that the Headrest should not be used to manoeuvre the chair.



BRAGG-H



BRAGG-L



Back view

## Features:

Adjustable seat height  
Adjustable seat and back angle  
Adjustable seat depth (seat slider)  
Adjustable arms

Auto weight tensioning  
Synchron mechanism with 3 locking positions  
640mm black high arch 5 star base

Available in black only  
Suitable for indoor use only

